

IOM manual

2013 rev 1

Instructions for installation, operation and maintenance.
Aseptic EHEDG certified diaphragm pumps in AISI 316L.

Pump models:

TX94
TX144
TX244



Read this instruction manual carefully,
before you install and operate the pump

topflo®

CONTENTS



Ch.	Content	Page	Ch.	Content	Page
	CE CERTIFICATE	3	5.	DATA	16
0.	GENERAL	4	5.1	Capacity curves	16
0.1	Introduction	4	5.2	Capacity changes	16
0.2	The warning symbols	4	5.3	Dimensions and technical data	17
0.3	EHEDG certification	4	5.4	Tightening torques	17
1.	INSTALLATION	5	6.	WARRANTY & REPAIR	18
1.1	Receiving inspection	5	6.1	Returning parts	18
1.2	Storage	5	6.2	Warranty	18
1.3	Foundation	5	6.3	Warranty form	20
1.4	Suction and discharge pipings	5			
1.4.1	Connection of suction pipe	5			
1.4.2	Connection of discharge pipe	5			
1.4.3	Optimizing the pipework layout for drainability	5			
1.5	Air connection	5			
1.5.1	Air treatment system	6			
1.6	Example of installation	6			
1.7	Recommended installations	6			
1.7.1	Flooded	6			
1.7.2	Selfpriming	6			
2.	OPERATION	7			
2.1	Health and safety	7			
2.1.1	Protection	7			
2.1.2	Environments in danger of explosion	7			
2.1.3	Air pressure	7			
2.1.4	Noise level	7			
2.1.5	Temperature hazards	8			
2.2	Before starting the pump	8			
2.3	Starting and operating	8			
2.3.1	Dry running	8			
2.3.2	Optimizing the pump lifetime	8			
2.4	Pump stopping	8			
2.5	Cleaning of the pump	9			
2.5.1	CIP - Clean in place	9			
3.	MAINTENANCE	10			
3.1	Performance test	10			
3.2	Routine inspection	10			
3.3	Complete inspection	10			
3.4	Location of faults	10			
3.7	Dismantling the pump	11			
3.7.1	Before the dismantling procedure	11			
3.7.2	Mainparts	11			
3.7.3	Center block	11			
3.8	Assembly of the pump	12			
3.8.1	Center block	12			
3.8.2	Assembling of the main units	12			
3.8.3	Test run	12			
4.	SPARE PARTS	13			
4.1	Spare part drawing	13			
4.2	Spare part list	14			
4.3	Stocking recommendation	15			
4.4	How to order parts	15			
4.5	Pump code	15			



Declaration of conformity

Machinery directive 2006/42/EEC, Annex 2A

Tapflo AB declares that:

Product name: **Air operated diaphragm pumps**
Models: **T...**

Is in conformity with the essential health and safety requirements and technical construction file requirements of the EC Machinery directive 2006/42/EEC, amended from directive 95/16/EEC.

Manufacturer: Tapflo AB

Address: Filaregatan 4
S-442 34 Kungälv
Sweden

Tapflo AB, January 2nd 2013

Håkan Ekstrand
Managing director

0. GENERAL



0.1 Introduction

The Tapflo Air Operated Diaphragm Pump range is a complete series of pumps for industrial applications. The pumps are designed to be safe simple and easy to use and maintain. The construction is sealless and without rotating parts. The pumps are suitable for a variety of duties in hygienic installations.

With proper attention to maintenance, Tapflo Pumps will give efficient and trouble free operation. This instruction manual will familiarise operators with detailed information about installing, operating and maintaining the pump.

0.2 The warning symbols

The following warning symbols are present in this instruction manual. This is what they say.



This symbol stands next to all safety instructions in this instruction manual where danger to life and limb may occur. Observe these instructions and proceed with utmost caution in these situations. Inform also other users of all safety instructions. In addition to the instructions in this instruction manual, the general safety and accident prevention regulations must be observed.



This signal stands at points in this instruction manual of particular importance for compliance with regulations and directives, for correct work flow and for the prevention of damage to and destruction of the complete pump or its subassemblies.

0.3 EHEDG certification

The Tapflo Aseptic series is EHEDG certified by the Danish Technological Institute. The EHEDG certification comprise both a hygienic design evaluation as well as CIP cleanability tests. Our aseptic pump TX94 was certified in April 2004.



1. INSTALLATION



1.1 Receiving inspection

Although precaution is taken by us when packing and shipping, we urge you to carefully check the shipment on receipt. Make sure that all parts and accessories listed on the packing list are accounted for. Immediately report any damage or shortage to the transport company and to us.

1.2 Storage



If the equipment is to be stored prior to installation, place it in a clean location. Do not remove the protective covers from the suction, discharge and air connections which have been fastened to keep pump internals free of debris. Clean the pump thoroughly before installation.

1.3 Foundation



The support of the pump is furnished with adjustable vibration absorbing rubber feet. Place the pump on a stable foundation, which is able to absorb vibrations. It is essential for the operation of the pump to mount the pump with the feet in a downward direction (see sketch in chapter 1.6).

1.4 Suction and discharge pipings

Suction and discharge piping should be fully supported and anchored near to but independent of the pump. The piping to the pump should be a hose, to prevent undue stress and strain on the pump connections and the pipings.

1.4.1 Connection of suction pipe

Remember that the suction pipe/connection is the most critical point, especially if the pump is priming. Just a small leakage will dramatically reduce the suction capability of the pump. When connecting the suction pipe, following is recommended.

- 1) For satisfactory operation, use reinforced hose (the suction power may otherwise shrink the hose), other flexible piping or rigid piping if use of hose is not allowed. The internal diameter of the hose should be the same as on the suction connection (at the bottom of the pump) to have best suction capability.
- 2) Make sure that the connection suction piping - pump is completely tight, otherwise the suction capability will be reduced.
- 3) Always use as short suction pipe as possible. Avoid air pockets which can arise with long pipings.

1.4.2 Connection of discharge pipe



For this connection it is only recommended a simple and positive flow connection. Use a hose or flexible piping (minimum one meter) between the discharge connection and any rigid fixed piping. Coil the hose at least one turn. All components (hose, pipe, valves etc) on the discharge piping must be designed for minimum PN 10.

1.4.3 Optimizing the pipework layout for drainability

The pump is designed to follow the EHEDG regulations, where one of the most important factors is the drainability. Apart from the pump it is also important that the whole pipe system is drainable. Horizontal surfaces must be avoided, as a general rule pipes should slope at least 3°.

1.5 Air connection

Screw the air hose into the air intake on the center block of the pump with for example a bayonet coupling. For best efficiency, use the same hose diameter as the internal diameter of the connection on the air intake.

1. INSTALLATION



1.5.1



Air treatment system

The air valve is constructed for oilfree air. Lubrication of the air is **not allowed**. However, if the air is **very dry** (laboratory air), the air may be lubricated with water. Maximum air pressure is 8 bar. As prevention purpose, a filtration of the air by means of a 5 micron filter or finer is recommended. Dirt in the air can under unfortunate circumstances be the cause of breakdown. Recommended air quality according to PN-ISO8573 is particles class 3, water class 4 and oil class 3.


To facilitate the operation of the pump we recommend an air treatment system connected to the air supply. These components should be included:

- 1) Regulator to adjust the air pressure
- 2) Manometer to read the actual pressure
- 3) Needle valve to adjust the air flow
- 4) Filter

These components are included in Tapflo **Air treatment system** which can be ordered from us.

1.6 Example of installation

- 1) Gate valve compressed air
- 2) Filter and pressure regulator
- 3) Flexible hose
- 4) Needle valve
- 5) Flexible piping
- 6) Gate valve suction
- 7) Gate valve discharge
- 8) Coiled flexible piping
- 9) Flow gauge



1.7 Recommended installations

The Tapflo pump is flexible in the way you are able to install it.

1.7.1

Flooded

The piping system is designed with a positive suction head. This is the best way of installation where it is necessary to completely evacuate all liquid from the container, or where viscous (thick) products are transferred.

1.7.2

Selfpriming

The Tapflo pump is designed to pull a high vacuum. It is able to evacuate an empty suction pipe without any damage to the pump. The suction lift is up to 5 meter (16.4 ') from an empty suction pipe and up to 8 meter (26.2') from a wetted pipe. The suction capability depends on the pump size (see chapter 5)

2. OPERATION



2.1 Health and safety

The pump must be installed according to local and national safety rules.



The pumps are constructed for particular applications. Do not use the pump on applications different from that for which it was sold without consulting us to ascertain its suitability.

2.1.1 Protection




In the interest of health and safety it is essential to wear protective clothing and safety goggles when operating, and/or working in the vicinity of Tapflo pumps.

2.1.2 Environments in danger of explosion - ATEX



Your aseptic EHEDG pump is ATEX approved (models TX...), follow below instructions and local/national rules for safe use.

ATEX (directive 94/9/EC) classification of Tapflo TX pumps:



Earth connection of pump and other equipment

Connect a suitable earth wire to the stainless steel earth connection that is placed on the inside of one of the pump housings. Connect the other end of the earthwire to earth and also make sure that other equipment like hoses/pipes/containers etc are properly earthed/connected.

2.1.3 Air pressure

The maximum air pressure for Tapflo pumps is 8 bar. Higher air pressure than 8 bar can damage the pump and may cause injury to personel in vicinity of the pump. If you intend to apply a higher air pressure than 8 bar, please consult us.

2.1.4 Noise level



At tests, the noise level from a Tapflo pump has not exceeded 80 dB(A). Under some circumstances, for example if the pump is operating under high air pressure at low discharge head, the noise can be inconvenient or hazardous for personel staying for long periods in vicinity of the pump. This hazard can be prevented by:

- using suitable ear protection
- lower the air pressure and/or raise the discharge head
- lead the outcomming air from the place by connecting a hose from the muffler connection of the pump. You will find the air exhaust dimension in chapter 1.7.3.
- use elastomer valve balls (EPDM) instead of PTFE or stainless steel, provided that the elastomer is compatible with the pumped liquid.

2. OPERATION



2.1.5

Temperature hazards



Raised temperature can cause damage on the pump and/or pipings and may also be hazardous for personel in the vicinity of the pump/pipings. Avoid quick temperature changes and do not exceed the maximum temperature specified when the pump was ordered. See also general max temperatures based on water in chapter 5 "Data".

2.2

Before starting the pump



- Make sure the pump is installed according to the installation instruction (section 1).
- Filling of the pump with liquid before start is not necessary.
- When installation is new or reinstalled, a test run of the pump with water should be conducted to make sure the pump operates normally and does not leak.
- When installation is new or reinstalled, check the pump housing nut tightening torque (see chapter 5.5 "Data"). After approx 1 week operation, the torque should be checked again. This is important to prevent leakage.



2.3

Starting and operating

- Open the discharge valve.
- ***Note! Considering the suction capacity when air is still in the suction pipe, it is recommended to start with low air pressure/flow in the beginning. This is not necessary if the pump is filled with liquid before start.***
- When the pump has been filled with liquid, the air pressure/flow may be raised to increase the suction capacity of the pump.
- The performance of the pump can be adjusted through the air supply by using a needle valve and a pressure regulator. The performance can also be adjusted by normal flow control on the discharge side of the system.

2.3.1

Dry running

The pump may run dry without any problem. If the pump runs dry for longer periods, it may cause premature wear of the components. Dry run protection systems are available, please contact us.

2.3.2

Optimizing the pump lifetime

Running at full frequency (maximum air pressure/flow) continuously will cause premature wear of the components. As a general rule, we recommend to run at half of the maximum capacity of the pump. For instance, a TX94 pump should run continuous maximum at 47 l/min.

2.4

Pump stopping

The pump can be stopped in two ways:

- 1) Close the discharge valve. The pressure from the system will stop the pump automatically. This will not do any damage to the pump. The pump restarts easy when the valve is opened again.
- 2) Stop the air supply.

2. OPERATION



2.5 Cleaning of the pump

2.5.1 CIP - Clean in place

The importance of easy cleaning is especially great in hygienic and aseptic applications. Tapflo aseptic pumps are designed for CIP (clean in place). This allows the pump to be internally cleaned without strip down. The pump can be cleaned by flushing through with a CIP fluid (usually a mild solution of sodium hydroxide and a sanitizing additive) or by injection of hot steam. The CIP fluid temperature varies, but in the sanitary field, the temperature is usually about 90°C. Make sure that the CIP fluid is compatible with the materials in the pump/piping (consult us for further information).

The solution is passed through the system by either from the operation of the pump itself, or by a centralized cleaning system. The CIP fluid must pass through the pump at a minimum velocity of 1.5 m/s in the normal flow direction (from inlet to outlet).

2.5.1.1 Drainage of the pump

After the CIP procedure, the pump usually has to be drained from the CIP fluid. The Tapflo aseptic series is supplied with a hygienic stand, enabling rotation of the pump unit for draining.

- 1) Disconnect the pump from the pipings.
- 2) Simply loosen the two domed nuts and rotate the pump and let the remaining fluid drain off.
- 3) Rotate back to normal position, connect the pump with the pipings and fix the domed nuts.



3. MAINTENANCE



3.1 Performance test

When installation is new, a test run of the pump should be conducted. Gauge the capacity at specific air pressure/flow. This information is for use in checking performance as wear takes place. You will be able to set schedules for maintenance of the pump and to select spare parts to be kept on stock.

3.2 Routine inspection



Frequent observation of the pump operation is recommended to detect problems. A change in sound of the running pump can be an indication of worn parts (see below "location of faults"). Leaking liquid from the pump and changes of performance may also be detected. Routine inspections should be conducted frequently.

3.3 Complete inspection



The intervals for a complete inspection depend upon the operation conditions for the pump. The characteristics of the liquid, temperature, materials used in the pump and running time decide how often a complete inspection is necessary.

If a problem has occurred, or if the pump is in need of a complete inspection, see later this chapter "location of faults" and "dismantling of the pump". You are of course warmly welcome to consult us for further help.

Worn parts should be carried in stock, see our recommendation in chapter 4.

3.4 Location of faults

Problem	Possible fault
The pump does not run	The air pressure is too low The air connection is blocked Muffler is blocked Air valve is defect Dirt in the pump chamber Diaphragm breakdown
The suction is bad	Suction connection is not tight Suction connection is blocked Muffler is blocked Valve balls are blocked Valve balls are damaged
The pump runs irregularly	Valve balls are blocked Sealings are defect in air valve or center block Diaphragm breakdown
Bad flow/pressure	Pressurefall in incoming air Suction or air connection blocked Muffler is blocked Air valve is defect Valve balls worn out/broken Air in liquid Diaphragm breakdown
Liquid leaks from the pump	Screws on the housing not properly fastened
Liquid comes out of the muffler	Diaphragm breakdown

3. MAINTENANCE



3.7 Dismantling the pump

For easier understanding, watch our maintenance videos on <http://www.tapflo.com/site/en/pages/maintenance-videos>

3.7.1 Before the dismantling procedure



Be sure to drain all liquid from the pump. Cleanse or neutralize the pump thoroughly. Disconnect the air connection and then the suction and discharge connections. Place the pump on a clean soft surface and use suitable gloves to avoid fingerprints and contamination of the pump.

The numbers put in brackets refer to the positions on the assembly drawing.

3.7.2 Mainparts

- 1) Unscrew and remove the clamps (1382) from the pump. Carefully remove the manifolds (131 and 132), valve ball stops (22), valve balls (23) and o-rings (18).
- 2) Unscrew the domed nuts (4) and lift off the pump unit from the support (17).
- 3) Unscrew and release the domed nuts (37) from one side of the pump. Place the pump with the housing (11) that still has the nuts on downwards. Then lift off the loose housing from the centerblock unit and then carefully pull the centerblock unit from the remaining housing with pin screws (14).

3.7.3 Center block

- 1) Press the diaphragms (15) to their neutral position (both have the same distance to the center block).
- 2) Hold one of the diaphragms and unscrew the other. Then pull out the remaining diaphragm with the diaphragm shaft (16).
- 3) Place the center block on a clean place. Observe that this is a faying surface, so be careful not to damage it.
TX94: Pull out the circlip (27) carefully with pliers so it will not hurt you or disappear.
TX144 and TX244: Unscrew the screws (2711) and lift off the plate (271).
- 4) Turn the center block.
TX94: Pull out the other circlip (27).
TX144 and TX244: Unscrew the screws (2711) and lift off the plate (271).
- 5) Press carefully out the air valve from the housing. The main piston and air valve housing will

3. MAINTENANCE



3.8 Assembly of the pump

For easier understanding, watch our maintenance videos on <http://www.tapflo.com/site/en/pages/maintenance-videos>

3.8.1 Center block

- 1) TX94: Mount the circlip (27) on one side. Put water on the air valve o-rings (30) and then carefully push the air valve (61) into the housing. Make sure that the o-rings (30) remain in the right position. Put the circlip (27) on the other side.

TX144 and TX244: Mount the plate (271) on one side by means of the screws (2711). Put water on the air valve o-rings (30) and then carefully push the air valve (61) into the housing. Make sure that the o-rings (30) remain in the right position. Put the plate (271) on the other side and fix the screws (2711).

- 2) Fix securely the pin bolts from the diaphragm shaft (16) in the diaphragms (15)
- 3) Put the diaphragm (15) with shaft (16) into the center block. Screw the next diaphragm (15) onto the shaft (16) and fix the holes. Sometimes you have to turn the diaphragms a little back to get the holes fixed.

3.8.2 Assembling of the main units

The housing is assembled in opposite order to dismantling.

- 1) Make sure all pin screws (14) have a domed nut (37) each. Nut should only be put on one or two threads.
- 2) Place one of the housings (11) on the centerblock and then gently put all the pin screws through the housing and centerblock. Be careful so that threads on screws do not damage the diaphragms when assembling.
- 3) Put on the remaining housing (11) onto the pin screws (14).
- 4) Fasten the domed nuts (37) by hand, then fasten alternately with a tool. After a few weeks operation a follow up draft of the nuts is recommended.
- 5) Place the pump unit on the support and fasten the domed nuts (174) only by hand, so that the pump unit can be turned.
- 6) Turn the pump unit until the inlet side is upwards. Place the o-rings (18), valve ball stops (22), valve balls (23) and then the inlet manifold (131) on the housing inlets.
- 7) Mount and fasten the clamps (1382).
- 8) Turn the pump unit and do the same procedure on the outlet side as described in step 6. Fasten the domed nuts (4).


The pump is now ready for service and can be reinstalled in the system according to section 1 and 2 (installation and operation).

3.8.3 Test run

We recommend you to conduct a test run of the pump before installing it to the system so no liquid gets wasted if the pump leaks or perhaps does not start according to wrong assembling of the pump.

4. SPARE PARTS

4.1 Spare part drawing TX94, TX144 and TX244



* = Plate mounted air valve standard on TX144 and TX244. Plates (271) and screws (2711) replace the circlips (27). Centerblock (122) is used.

4. SPARE PARTS



4.2 Spare part list TX94, TX144 and TX244

Pos	Description	Qty/pump	Material options	Kit Liq	Kit Air
4	Domed nut	2	AISI 316L		
5	Washer	2	AISI 316L		
11L	Housing left side	1	AISI 316L		
11R	Housing right side	1	AISI 316L		
12*	Center block	1	Conductive PP		
131	Manifold inlet	1	AISI 316L		
132	Manifold outlet	1	AISI 316L		
1382	3-clamp	4	AISI 316L		
14	Pin screw	6/8***	AISI 316L		
15	Diaphragm	2	EPDM (FDA), PTFE TFM 1705 (FDA & USP VI), PTFE TFM 1705B (FDA & USP VI), White EPDM (FDA) or PTFE with white back (FDA & USP VI)	•	
16	Diaphragm shaft	1	AISI 316L		•
17	Stand	1	AISI 316L		
1717	Adjustable foot set	4	AISI 316L		
18	O-ring	8	FEP/FKM (standard, FDA & USP VI), EPDM (FDA) or EPDM (FDA & USP VI)	•	•
22	Valve ball stop	4	AISI 316L		
23	Valve ball	4	PTFE (FDA), PTFE TFM (FDA & USP VI), EPDM, EPDM (FDA) or AISI 316L	•	
25	Muffler	1	PP		•
26	Air intake adapter	1	Galvanized brass		
27*	Circlip	2	Cr3 treated steel		
30	O-ring	6	NBR (standard), EPDM or FKM		
36	Center block sealing	2	PE		•
37	Domed nut	12/16***	AISI 316L		
38	Washer	12/16***	AISI 316L		
47	O-ring (back up for 36)	2/4**	NBR (standard), EPDM or FKM		•
61	Air valve complete	1	Body brass (standard), AISI 316 or PET, o-rings NBR (standard), EPDM or FKM		•
90	Earth connection kit	1	AISI 316L		
Plate mounted air valve, standard on TX144 and TX244					
122	Center block	1	Conductive PP		
271	Set 2 x plates (L and R)	1	AISI 316L		
2711	Screw	8	AISI 316L		
* = Used on TX94 only, for TX144 and TX244 see "Plate mounted air valve" above					
** = TX144 only					
*** = TX244 only					

4. SPARE PARTS



4.3 Stocking recommendation

Even at normal operation some details in the pump will be subject to wear. In order to avoid expensive breakdowns we recommend having a few spare parts in stock.


Depending on the severity of the operation and the importance of not having a breakdown we offer two different spare part kits, kit LIQ and kit AIR. kit LIQ includes worn parts on the liquid side, while kit AIR includes worn parts on the air side. In the spare part lists you find which parts are included in respective kits.

4.4 How to order parts

When ordering spare parts for Tapflo Pumps, please let us know the **model number** from the nameplate of the pump. Then just indicate the part numbers (referred to the spare part list) and quantity of each item.

4.5 Pump code

The model number on the pump tells the pump size and material of the pump components.






* = Ask us for complete pump code with all available options and executions

5. DATA



5.1 Capacity curves


The performance curves are based on water at 20°C. Other circumstances might change the performance. See below how the capacity will change at different viscosities and suction lifts.




Recommended flow is half of the the max flow, i.e. recommended flow for a TX94 is 47 l/min.

5.2 Capacity changes

Capacity changes at different suction lifts



Capacity changes at different viscosities




5. DATA

5.3 Dimensions and technical data

Data			
Model	TX94	TX144	TX244
Max flow	94 l/min	144 l/min	330 l/min
Max pressure	8 bar	8 bar	8 bar
Max air pressure	8 bar	8 bar	8 bar
Dry suction lift	2 m	3 m	4.4 m
Max solid size	6 mm, bigger if soft	6 mm, bigger if soft	10 mm, bigger if soft
Temperature	-20° +110° C (temporary higher)		
Weight	15 kg	22 kg	46 kg
Connections	Triclamp (standard), SMS, DIN and RJT threads, DIN 11864 clamp		
ATEX details	Group II, cat 2, T4		
Materials and options			
Housing, manifolds	AISI 316L, Ra 0.8 Ra 0.5 on request		
Diaphragms	PTFE (FDA & USP VI) PTFE 1705B (solvents, FDA & USP VI) EPDM (FDA on request) White EPDM (FDA) PTFE with white back (FDA & USP VI)		
Valves (ball type)	PTFE (FDA) PTFE (USP VI & FDA) EPDM (FDA on request) AISI 316L		
O-rings	EPDM (FDA) EPDM (USP VI & FDA) FEP/FKM (FDA)		
Options	Backup diaphragm system		

Dimensions (mm)			
Model	TX94	TX144	TX244
A	260	280	360
B	275	278	340
E	447	488	700
H	185	188	270
J	DN 40	DN 50	DN 65



5.4 Tightening torques

The following tightening torques are recommended for the housing nuts.

Pump size	Mounting torque (Nm)
TX94	8
TX144	16
TX244	20

6. WARRANTY & REPAIR



6.1 Returning parts

When returning parts to Tapflo AB please follow this procedure:

- Consult Tapflo AB for shipping instructions.
- Cleanse or neutralize and rinse the part/pump. Make sure the part/pump is completely empty from liquid.
- Pack the return articles carefully to prevent any damage under transport.

Goods will not be accepted unless the above procedure has been complied with.

6.2 Warranty

Tapflo warrants products under conditions as below for a period of not more than 5 years from installation and not more than 6 years from date of manufacture, whichever comes first.

1. The following terms and condition apply to the sale of machinery, components and related services and products, of Tapflo (hereinafter “the products”)
2. Tapflo (the manufacturer) warrants that:
 - a.) its products as being free of defects in material, design and workmanship at the time of original purchase;
 - b.) its products will function in accordance with Tapflo operative manuals; Tapflo does not guarantee that the product will meet the precise needs of the Customer, except for those purposes set out in any invitation to render documents or other documents specifically made available to Tapflo before entering into this agreement;
 - c.) high quality materials are used in the construction of the pumps and that machining and assembly are carried out to the highest standards.

Except as expressly stated above, Tapflo makes no warranties, express or implied, concerning the products, including all warranties of fitness for a particular purpose.

3. This warranty shall not be applicable in circumstances other than defects in material, design, and workmanship. In particular warranty shall not cover the following:
 - a.) Periodic checks, maintenance, repair and replacement of parts due to normal wear and tear (seals, O-rings, rubber items, diaphragms, air valves etc.);
 - b.) Damage to the product resulting from:
 - b.1.) Tampering with, abuse or misuse, including but not limited to failure to use the product for its normal purposes as stated at the time of purchase or in accordance with Tapflo instructions for use and maintenance of the product, or the installation or improper ventilation or use of the product in a manner inconsistent with the technical or safety standard in force;
 - b.2.) Repairs performed by non-skilled personnel or use of non-original Tapflo parts
 - b.3.) Accidents or any cause beyond the control of Tapflo, including but not limited to lightning, water, fire, earthquake, and public disturbances, etc.;
4. The warrantee shall cover the replacement or repairing of any parts, which is documented faulty due to construction or assembling, with new or repaired parts free of charges delivered by Tapflo. Parts subjected to normal tear and wear shall not be covered by the warranty. Tapflo shall decide as to whether the defective or faulty part shall be replaced or repaired.
5. The warrantee of the products shall be valid for a period in accordance to the current law from the date of delivery, under the condition that notice of the alleged defect to the products or parts thereof be given to Tapflo in written within the mandatory term of 8 days from the discovery.

6. WARRANTY & REPAIR



6. Repair or replacement under the terms of this warranty shall not give a right to an extension to, or a new commencement of, the period of warranty. Repair or replacement under the terms of this warranty may be fulfilled with functionally equivalent reconditioned units. Tapflo qualified personnel shall be solely entitled to carry out repair or replacement of faulty parts after careful examination of the pump. Replaced faulty parts or components will become the property of Tapflo
7. The products are built in accordance with standard CE normative and are tested (where applicable) by Tapflo. Approval and tests by other control authority are for the customer's account. The products shall not be considered defective in materials, design or workmanship if they need to be adapted, changed or adjusted to conform to national or local technical or safety standards in force in any country other than that for which the unit was originally designed and manufactured. This warranty shall not reimburse such adaptations, changes or adjustments, or attempt to do so, whether properly performed or not, nor any damage resulting from them, nor any adaptation, change or adjustments to upgrade the products from their normal purpose as described in the products operative manual without the prior written consent of Tapflo
8. Installation, including electric and other connections to utility mains according to Tapflo drawings, is for the cost and responsibility of the customer, unless otherwise agreed in writing.
9. Tapflo will not be liable on any claim, whether in contract, tort, or otherwise, for any indirect, special, incidental, or consequential damages, caused to the customer or to third parties, including loss of profits, arising by any possible infringement of par. 3 above or by the customer or third parties being in the impossibility of using the products.

Study the above, Tapflo liability to the customer or third parties from any claim, whether in contract or otherwise, shall be limited to the total amount paid by the customer for the product that caused the damages.

□

Company: _____			
Telephone: _____		Fax: _____	
Address: _____			
Country: _____		Contact name: _____	
E-mail: _____			
Delivery date: _____		Pump was installed (date): _____	
Pump type: _____		Serial No (stamped on the pump housing): _____	
Description of the fault: _____			

The installation			
Liquid: _____			
Temperature (°C): _____	Viscosity (cPs): _____	Spec. grav. (kg/m³): _____	pH-value: _____
Contents of particles: _____ %, of max size (mm): _____			
Flow (l/min): _____	Duty (h/day): _____	No of starts per day: _____	
Discharge head (mwc): _____		Suction head/lift (m): _____	
Air pressure (bar): _____		Quality of the air (filter, micron?, lubrication?): _____	
Other: _____			

Place for sketch of the installation			







www.tapflo.com

Austria

Tapflo GmbH
Tel: +43 732 27292920
sales@tapflo.at

Belarus

Tapflo Belarus
Tel: +375 17 3121370
sales@tapflo.by

Bulgaria

Tapflo EOOD
Tel: +359 (2) 974 18 54
sofia@tapflo.org

Czech & Slovakia

Tapflo s.r.o.
Tel: +420 548 138 660
tapflo@tapflo.pump.cz

China

Tapflo (Wuxi)
Tel: +86 510 8241 7602
sales@tapflo.cn

Denmark

Tapflo Danmark
Tel: +45 36 454600
info@tapflo.dk

France

Tapflo France
Tel: +33 1 34 78 82 40
info@tapflo.fr

India

Tapflo Pumps (India)
Tel: +91 44 26534479
tapfloindia@gmail.com

Ireland

Tapflo Ireland Ltd
Tel: +353 1 2011911
info@tapflo.ie

Italy

Tapflo Italia
Tel: +39 0362307698
info@tapfloitalia.com

Kazakhstan

Tapflo Kazakhstan
Tel: +7 727 256 05 45
sales@tapflo.kz

Latvia

Tapflo Latvia
Tel: +371 67472205
riga@tapflo.lv

Poland

Tapflo Sp. z o.o.
Tel: +48 58 5301181
gda@tapflo.pl

Romania

S.C. Tapflo Rom. S.r.l.
Tel: +40 21 3451255
sales@tapflo.ro

Russia

Tapflo Company
Tel: +7 495 232 18 28
sales@tapflo.com.ru

Serbia

Tapflo d.o.o.
Tel: +381 21 44 58 08
sales@tapflo.rs

Spain

Tapflo Iberica
Tel: +34 677 47 89 25
avives@tapfloiberica.es

South Africa

Tapflo (Pty) Ltd
Tel: +27 31 701 5255
sales@tapflo.co.za

Turkey

Tapflo Makina Ltd
Tel: +90 216 467 33 11
sales@tapflo.com.tr

Ukraine

TOB Tapflo
Tel: +380 44 222 68 44
sales@tapflo.com.ua

United Kingdom

Tapflo (UK) Ltd
Tel: +44 2380 252325
sales@tapflo.pumps.co.uk

Tapflo AB

Filaregatan 4
S-442 34 Kungälv, Sweden

Tel: **+46 303 63390**
Fax: **+46 303 19916**
Tech support **support@tapflo.com**
Orders **order@tapflo.com**